



Model 74012uk
1 player / Ages 8 and up
INSTRUCTION MANUAL

P/N 82381110 Rev.A

E 1

YES / NEW GAME - Use this button for the following:

Answer "yes" to a question or prompt

Wake the unit from "sleep mode"

Start a new game by pressing and holding

NO - Use to answer "no" to a question or prompt

SOMETIMES - Press to answer "depends" or "maybe" to a question or prompt

UNKNOWN - This answers irrelevant or "unknown" to a question or prompt.

SOUND - This button turns the sound on and off (a high tone indicates sound is on, a low tone when sound is off).

LEFTSIDE & RIGHTSIDE SCROLL BUTTON - Use these two buttons to move forward or backward through a menu, or return to a previous section. Pressing the LEFTSIDE SCROLL will also increase the text scrolling speed. Pressing RIGHT SCROLL will slow it down.

RESET - When a blunt point is inserted, this button resets the game to its original settings.

SLEEP MODE - After 60 seconds of inactivity, the game will automatically shut down, going into "sleep mode". To turn it on again and resume your game, simply press the **YES / NEW GAME** button.

HOW TO PLAY

Although you'll never beat me, I'll tell you how to play anyway!

First, press the **YES / NEW GAME** button to begin a new game.

Next, I will ask if you're thinking of an: animal, vegetable, mineral, other, or unknown.

Use the **LEFT SCROLL** and **RIGHT SCROLL** buttons to select your choices. Then press the **YES / NEW GAME** button to enter your answer.

Now I will ask you a series of questions. Answer honestly by pressing one of the answer buttons. Your answer would be yes, no, sometimes, or unknown.

After a series of 20 questions, I will try to guess what you're thinking. If I guess correctly, press the **YES / NEW GAME**. If for some strange reason, I guess wrong, I will ask you 5 more questions then guess again.

When I guess what you're thinking, I win! If all my guesses are wrong, you win. But don't worry, that will never happen.

Good Luck! You're going to need it!


I KNOW WHAT YOU'RE THINKING!

You don't believe me, do you? Well, you soon will! Just think of an everyday object and I will ask you few simple questions. Answer the questions honestly, and I will tell you what you're thinking! Scary, isn't it?

BUTTONS AND FEATURES

Press to increase speed of text and move backward through text

Press to decrease speed of text and move forward through text



BATTERY INSTALLATION

This game is powered by two (2) AAA (LR03) batteries.

- Using a screwdriver, loosen the screw until the battery compartment door can be removed.
- Insert two (2) AAA (LR03) batteries (we recommend alkaline) as indicated inside the battery compartment.
- Replace the battery compartment door and tighten the screw with a screwdriver. Do not over-tighten.

ADULT SUPERVISION IS RECOMMENDED WHEN CHANGING BATTERIES.

CAUTION

- As with all small batteries, the batteries used with this game should be kept away from small children who might still put things in their mouths. If a battery is swallowed, consult a physician immediately.
- Be sure you insert the battery correctly and always follow the game and battery manufacturer's instructions.
- Do not dispose of batteries in fire.
- Batteries might leak if improperly installed, or explode if recharged, disassembled or heated.

MAINTENANCE

- Handle this game carefully.
- Store this game away from dusty or dirty areas.
- Keep this game away from moisture or temperature extremes.
- Do not disassemble this game. If a problem occurs, press the Reset button or remove and replace the batteries to reset the computer, or try new batteries. If problems persist, consult your warranty information located at the end of this instruction manual.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Do not use rechargeable batteries.
- Do not attempt to recharge non-rechargeable batteries.
- Remove any exhausted batteries from the game.
- The supply terminals are not to be short circuited.
- Insert batteries with the correct polarity.

Please retain this for future reference.

90-DAY LIMITED WARRANTY

(This product warranty is valid in the United Kingdom only)

All products in the RADICA® range are fully guaranteed for a period of 6 months from the original purchase date under normal use, against defective workmanship and materials (batteries excluded). This warranty does not cover damage resulting from accident, unreasonable use, negligence, improper service or other causes not arising out of defects in material or workmanship.

In the unlikely event that you do experience a problem within the first 6 months, please telephone the UK Technical Support team: Tel. 0906 213 0001 (call cost 25p a minute).

IMPORTANT: Always test the product with fresh alkaline batteries. Even new batteries may be defective or weak and low battery power is a frequent cause of unsatisfactory operation.

YOUR STATUTORY RIGHTS ARE NOT AFFECTED.



Calls are charged at 25p per minute and will show up on your standard telephone bill. Helpline hours are 8am - 11 pm, 7 days a week.

Distributed by:

RADICA U.K. Ltd.

The Old Stables, Munns Farm,
Cole Green, Hertfordshire,
SG14 2NL, England

Play on-line at www.20Q.net. Marketed under license from 20Q.net, Inc. All rights reserved.

RADICA:®

20Q IS A TRADEMARK OF 20Q.NET, INC.
USED UNDER LICENSE BY RADICA GAMES LTD.

© 2003 RADICA GAMES LTD.

PRODUCT SHAPE™

ALL RIGHTS RESERVED